




USER MANUAL

ETHERNET GATEWAY – Appendix 1 (Eng 01)

How to use this manual

Thanks for choosing this innovative ISEO product.

This user manual was compiled to offer a guide on the installation of SIRIO.

For the installation of the devices, set-up of the opening and other operations not described herein, refer to the installation and configuration manuals, available in the download area of ISEO Zero1's website, at:

www.iseozero1.com

The installation, initial set-up and changes to the setting, require the intervention of qualified staff, properly trained by ISEO Zero1.

- Read this manual prior to use the device in order to ensure a safe and proper use
- Preserve this manual as future reference

Informative icons

Please familiarise with the icons below, for an easy reading of the manual:



Warning: it indicates situations that could cause harm to people or animals



Be careful: it indicates situations that could cause damages to the device or other equipment



Note: it indicates notes, suggestions and additional information


Information on copyright

The rights concerning all technologies and products which are part of this device, belong to the relative holders.


Ethernet Gateway Configuration on Vega

To configure an Ethernet Gateway on Vega, from the Atlas list, select the one where you want to connect it and follow the next steps:


- 1) change the «Channel Type» from LOCKBUS (default) to **RS485**




- 2) add a new reader selecting the label «Readers»



and then select «+» button



- 3) - insert «Name of Reader»
- set «Channel of Reader» as 00
- enable the «Validator Function»



Click the «save» button [1] and turn back at Main Controller page and click the «save» button to update the global configuration. The Ethernet Gateway is properly setted!



www.iseo.com

Iseo Serrature s.p.a.
Via San Girolamo 13
25055 Pisogne (BS)
Italy
Tel +39 0364 8821
Fax +39 0364 882263
iseo@iseo.com

Iseo Serrature s.p.a.
Via Don Fasola 4
22069 Rovellasca (CO)
Italy
Tel +39 02 96740420
Fax +39 02 96740309
www.iseozero1.it

ISEO Zero1
ELECTRONIC SUPPORT SERVICE
iseozero1@iseo.com

800-728722
numero verde gratuito